# PC-451(Recessed Handle)

\*\*Please read the installation instruction before installation. Please do not dispose of the installation sheet after installation, instead please pass it to the product user for safe keeping

# Safety Warning

Before installation, please read the "Safety Warning" to ensure proper installation of product.

■ in the events of installation the possible situations that may occur leading to harm of the user will be stated below.



Column with the following tag indicates content that may lead to risks of death or serious injuries



Column with the following tag indicates content that may lead to injuries and product damage




This tag indicates content that should be avoided



Please carry out all actions with the following tag.

### △警告 About Installation

Please adhere to the dimensions given for hole cutting.



Over-tightening of Installation Screws may damage the door.



After installation, please check product once more to make sure product has been firmly secured.

If product is not installed firmly, product might wobble or there might be risk of product falling off, resulting in injuries

## △警告 About Product Usage


Please do not use product for unintended purposes or application. Product failure may result in injuries.



Please do not subject product to load capacity and impact force larger than what is stated. Product failure may occur, increasing the risk of injuries.

### △注意 About Product Maintenance


Wipe away all stains of cosmetics and medicinal products when found. Leaving stains for long term on the product may result in color change or corrosion which will increase the risk of product breakage and injuries



# Receesed Handle Type PC-451 Product Code Material Zinc.PET **Product Dimension** 223.9 × 53.5 × 25.7 mm 0 223.9

製品仕様

### Included in Package (Please check)





Installation

Screw A x2





 $\phi 4 \times 20$ Installation

Screw B x2



Spring Washer x2

### Installation Procedure

Cover x1

### @Installation Procedure

- (1) Fix one side of the Main Body with the provided Installation Screw, starting with A and finishing with B.
- ②Repeat step 1 for the other Main Body.
- 3) Paste Cover onto the space between Main Body.

## Hole cutting dimension

