

Door Handle Installation Instruction Sheet

DH-751

* Please be sure to read before installing product.

* Do not dispose the installation sheet after installation, instead please pass it to the product user.

◎ Installation Procedure

1. Drill two $\varnothing 9$ holes with pitch 100mm.
2. Install Handle A to door by fixing Pedestal, Spring Washers, and Installation Screws on the other side of the door.
3. Fix Handle B onto Pedestal and secure with Fixing Screws.

⚠ Caution: About installation

- * This product can be installed on doors 28~40mm thick.
- * Do not install product on ALC (Autoclaved lightweight concrete), lightweight metal, or spaces between concrete blocks.
- * After installation, please check to ensure product has been installed properly. If product has not been installed properly, it may wobble and drop off.
- * Do not install product in areas with very high temperature. It may damage the product and cause it drop off.

⚠ Caution: About product usage

- * Do not use product for unintended purpose or application. Product failure may result in injury.
- * Do not use gasoline (Benzene), thinner, alcohol, or acidic/alkaline based detergent and/or cleanser to clean the product.

